

Stroboframe®

ANTI-TWIST PLATES - Prevent camera from twisting off axis from flash. Register and lock camera in position on bracket. Ultra-thin plates mount via locating pins on camera platform. Recommended for use with all brackets (not compatible with Quick Flips). Required for use with Stroboflip bracket. See guide below for AT-Plate compatibility and catalog number.

Digital Camera	Anti-Twist Plate Catalog Number
Canon EOS 10D	300-EOS
Canon EOS 10D w/ Battery Pack	Cork Pad*
Canon EOS Digital Rebel	300-EOS
Canon EOS Digital Rebel w/ Vertical Grip	Cork Pad*
Canon EOS 1D	300-BE1
Canon EOS 1Ds	300-EOS
Fujifilm FinePix S2 Pro	300-FS1
Fujifilm FinePix S3 Pro	300-FS1
Fuji Finepix S7000	300-SLR
Kodak DCS Pro 14n	Cork Pad*
Kodak Easyshare DX6490	Cork Pad*
Nikon D1x	300-NF5
Nikon D2h	300-EOS
Nikon D70	300-NF4
Nikon D100	300-SLR
Nikon Coolpix 5700	Cork Pad*
Olympus E-1	Cork Pad*
Olympus E-1 w/ Battery Pack	Cork Pad*
Pentax *istD	300-SLR

* AT-Plate not applicable; cork pad (supplied with all Stroboframe brackets) provides adequate anti-twist prevention.