

4 Piece, 7-in-1 Accessory Kit

Maximizes use of Digital/Photo Camera or Camcorder.



1. Camera & Tripod Bag -

Carry and protect tripod, camera and accessories.



2. Camera Bag -

Tripod bag can be switched to camera bag only.



3. Full Size Aluminum Tripod -

Maximum height of 59" when using "SwitchGrip®" accessory (included).



4. Mini Ballhead Tripod -

For tabletop shooting.



5. "SwitchGrip®" Accessory -

Extends tripod height by 6 inches and allows the use of either a ball head or pan head for shooting.



6. Copy Stand -

"SwitchGrip®" can be set for difficult angle shots.



7. Multiple Device Holder -

Option to shoot with two cameras, camera and flash, or other equipment.

SwitchKit™ includes:

- Carry-All Combo Tripod/Camera Bag (folds to camera bag only)
- 53" Full-Size Tripod
- SwitchGrip® Handle
- Mini Ballhead Tripod



SwitchGrip®
Patent #2,921,587



Camera/Tripod bag easily converts to a Tripod Bag!

