

Recommended Anti-Twist Plates

All DSLR/HDSLR and Medium Format

300-ATP (*New Universal Camera AT Plate)

*Recommended with 300-BASE (QR Base); however, will attach to camera platform of 310-700, 310-900, 310-750, 310-755, 310-800 and 310-810 with supplied hardware.

Digital Cameras	Anti-Twist Plate
IF YOUR CAMERA BODY IS NOT LISTED, THEN IT <i>REQUIRES</i> THE 300-ATP. HOWEVER, THE 300-ATP IS COMPATIBLE WITH ALL BODIES LISTED BELOW.	
Canon EOS 10D	300-EOS
Canon EOS 20D	300-SLR
Canon EOS 20D w/BG-E2 Battery Pack	300-BE1
Canon EOS 30D	300-SLR
Canon EOS 30D w/Battery Pack	300-BE1
Canon Digital Rebel	300-EOS
Canon Digital Rebel w/ Vertical Grip	300-BE1
Canon Digital Rebel XT & Xti	300-SLR
Canon Digital Rebel XT & XTi w/ Vertical Grip	300-BE1
Canon Digital Rebel XS & Xsi	300-SLR
Canon Digital Rebel XS & XSi w/ Vertical Grip	300-BE1
Canon EOS 1D	300-BE1
Canon EOS 1Ds	300-EOS
Canon EOS 1D Mark II	300-BE1
Canon EOS 1Ds Mark II	300-BE1
Canon EOS 1D Mark III	300-BE1
Canon EOS 5D	300-EOS
Canon EOS 5D MkII	300-EOS
Canon EOS 20D	300-SLR
Canon EOS 30D	300-SLR
Canon EOS 30D w/ BG-E2N	300-BE1 or 300-NF5
Canon EOS 40D	300-SLR
Canon EOS 40D w/ BG-E2N	300-BE1 or 300-NF5
Canon EOS 50D	300-SLR
Canon EOS 50D w/ BG-E2N	300-SLR
Fuji FinePix S3, S4 & S5 Pro	300-SLR
Fuji FinePix S7000	300-SLR
Nikon D1x	300-NF5
Nikon D1h	300-BE1
Nikon D2h and D2x	300-EOS
Nikon D2hs	300-BE1
Nikon D3	300-BE1
Nikon D40 and D40x	300-SLR
Nikon D60	300-SLR
Nikon D70	300-NF4
Nikon D80	300-SLR
Nikon D80 w/ MBD80	300-BE1 or 300-NF5
Nikon D90	300-SLR
Nikon D90 w/ MBD80	300-SLR or 300-NF5
Nikon D100	300-SLR
Nikon D200	300-SLR
Nikon D200 w/ MB200	300-BE1 or 300-NF5
NOTE: Any Nikon with a MB200 or MBD80 uses a 300-BE1 or 300-NF5; however door is blocked.	
Pentax *istD	300-SLR
Pentax K10D	300-SLR
Pentax K100D	300-H35